

- SeaNet Cables, Penetrators, and Accessories




Figure 2 SeaNet contact and conductor characteristics

Signal paths for the “SLAVE TO MASTER” and “MASTER TO SLAVE” conductor designations are illustrated in **Figure 3**.




Figure 3 Master and slave designations in UHD control system

1.7 Status Indicator LEDs

You can monitor SeaNet power and signal (signal/video) lines by using status indicator LEDs visible in one of the connector heads on every SeaNet cable (**Figure 4**).




Figure 4 Power and signal status indicator LEDs

- All LEDs flash briefly as a self-test when the Node port is turned on.
- The spare signal line (4) has no status LED.